



Color | For your eyes only | jumbo eye pencil | CC-EYE-022-11 | stick

This midnight blue liner glides on easily, adding drama and definition to your eyes. The creamy formula lasts all day without smudging.

Phase	Tradename	INCI (EU)	Supplier	%
A	Isopropyl Myristate	Isopropyl Myristate	BASF	ad 100
	Fancol ID-CG	Isododecane	Elementis	11.40
	KahlPolymer 7791 PE	Polyethylene	KahlWax	3.50
	KahlWax 2811 Rice	Oryza Sativa Bran Cera	KahlWax	3.50
	KahlWax 1899 Micro	Cera Microcristallina	KahlWax	12.50
	KahlWax 1847 Micro	Hydrogenated Microcrystalline Cera	KahlWax	5.50
	KahlResin 6723 Shorea Robusta + Octyldodecanol	Shorea Robusta Resin, Octyldodecanol	KahlWax	2.80
B	Carbon Black Powder	CI 77266	Kingfisher Colors	1.50
	SunCroma Ultramarine Blue C431810	CI 77007	Sun Chemical	6.20
	FD&C Blue Castor Oil Disp COD 8007	Ricinus Communis Seed Oil, CI 42090	Sun Chemical	6.80
	White Castor Oil Disp COD 8008	Ricinus Communis Seed Oil, CI 77891	Sun Chemical	0.60
C	Dowsil MQ-1600 Solid Resin	Trimethylsiloxysilicate	Dow Chemical	17.80
D	SunShine Super Blue C81-3250	Synthetic Fluorhlogopite, Titanium Dioxide	Sun Chemical	3.00

Procedure

Melt ingredients of phase A at 85 °C. Add phase B and homogenize for 1–2 minutes by using an ultraturrax. Add phase C during homogenization and continue until a uniform blend is obtained. Add phase D, cool to 80 °C, and mold.

If you prefer to use pure pigment split the dispersion to 50 % pure pigment and 50 % castor oil. Add castor oil to phase A. Mix pigments with a part of phase A and grind by using a mill.

Specification values

Appearance: midnight blue stick

Stability: passed three months at RT, 40 °C, and 50 °C